


2005 KX™125 PARTS DIAGRAM

Transmission



2005 KX™125 PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT,13T (Ref # 13127)	13127-0017	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1257	1
SPROCKET-OUTPUT,12T (Ref # 13144)	13144-0019	1
SPROCKET-OUTPUT,13T (Ref # 13144A)	13144-0020	1
GEAR,OUTPUT LOW,31T (Ref # 13260)	13260-1752	1
GEAR,OUTPUT 3RD,26T (Ref # 13260A)	13260-1754	1
GEAR,INPUT TOP,25T (Ref # 13262)	13262-0058	1
GEAR,OUTPUT 4TH,22T (Ref # 13262A)	13262-0095	1
GEAR,OUTPUT 2ND,26T (Ref # 13262B)	13262-0117	1
GEAR,INPUT 2ND,14T (Ref # 13262C)	13262-0118	1
GEAR,INPUT 3RD&4TH,17T&17T (Ref # 13262D)	13262-0174	1
GEAR,OUTPUT 5TH,27T (Ref # 13262E)	13262-0175	1
GEAR,OUTPUT TOP,25T (Ref # 13262F)	13262-0176	1
GEAR,INPUT 5TH,24T (Ref # 13262G)	13262-1055	1
WASHER,17.3X28X1 (Ref # 92022)	92022-255	1
BUSHING,OUTPUT,2ND (Ref # 92028)	92028-1732	1
RING-SNAP,25MM (Ref # 92033)	92033-1089	1
RING-SNAP,20MM (Ref # 92033A)	92033-1231	1
RING-O,19.5X1.5 (Ref # 92055)	92055-055	1
COLLAR (Ref # 92152)	92152-0189	1