


## 1987 PARTS DIAGRAM

Air Filter



## 1987 PARTS LIST

Air Filter

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-1142	1
CAP,AIR FILTER (Ref # 11012)	11012-1167	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1037	1
BRACKET,AIR FILTER (Ref # 11034)	32070-038	1
COVER,AIR FILTER,LH (Ref # 14024)	14025-1263	1
COVER,AIR FILTER,RH (Ref # 14024A)	14025-1264	1
DUCT,AIR FILTER,OUTLET (Ref # 14073)	14073-1048	1
DUCT,AIR FILTER,INTAKE (Ref # 14073A)	14073-1049	1
VALVE,AIR SWITCH (Ref # 16126)	16126-1014	1
SILENCER-INTAKE (Ref # 39162)	39162-1003	1
FITTING,TUBE,T-TYPE (Ref # 92005)	92005-1017	1
SCREW,TAPPING,5X12 (Ref # 92009)	92009-1319	1
CLAMP,TUBE (Ref # 92037)	92037-072	1
CLAMP,TUBE (Ref # 92037A)	92037-1076	1
CLAMP,TUBE (Ref # 92037B)	92037-213	1
TUBE,4X9X155 (Ref # 92059)	92059-1033	1
TUBE,4X9X370 (Ref # 92059A)	92059-1132	1
TUBE,14X20X89 (Ref # 92059B)	92059-1155	1
TUBE,AIR FILTER (Ref # 92059C)	92059-1156	1
TUBE,14X20X325 (Ref # 92059D)	92059-1161	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1042	1
SPRING,COIL,BLACK (Ref # 92081)	92081-1457	1
BOLT-UPSET-WSP (Ref # 187)	187B0612	1
SCREW-PAN-WP-CROS (Ref # 224)	224B0612	1