



## 1987 PARTS DIAGRAM

Engine Cover

E1431-0105



## 1987 PARTS LIST

Engine Cover

ITEM NAME	PART NUMBER	QUANTITY
GASKET,TRANSMISSION COVER (Ref # 11009)	11009-1163	1
GASKET,CLUTCH COVER (Ref # 11009A)	11009-1210	1
GASKET,CLUTCH ADJUSTING COVER (Ref # 11009B)	11009-1211	1
GASKET,PULSING COIL COVER (Ref # 11009C)	11009-1220	1
GASKET,GENERATOR COVER (Ref # 11009D)	14045-014	1
GASKET,RH ENGINE COVER (Ref # 11009E)	14046-023	1
COVER,TRANSMISSION (Ref # 14024)	14025-1240	1
COVER,ENGINE,RH (Ref # 14024A)	14025-1243	1
COVER,CLUTCH RELEASE (Ref # 14024B)	14025-1249	1
COVER,PULSING COIL (Ref # 14024C)	14025-1614	1
COVER-CHAIN (Ref # 14026)	14026-1063	1
COVER-GENERATOR (Ref # 14031)	14031-1056	1
COVER-CLUTCH (Ref # 14032)	14032-1047	1
GAUGE,OIL LEVEL (Ref # 52005)	52005-1009	1
WASHER,6.1X12X1 (Ref # 92022)	92022-077	1
PIN,DOWEL,6.3X8X14 (Ref # 92043)	92042-007	1
SEAL-OIL,SB12205 (Ref # 92049)	92049-004	1
SEAL-OIL,CLUTCH RELEASE (Ref # 92049A)	92049-1003	1
SEAL-OIL,SD-8187 (Ref # 92049B)	92049-1017	1
SEAL-OIL,SC32487 (Ref # 92049C)	92049-1033	1
SEAL-OIL,AE2343F0 (Ref # 92049D)	92049-1070	1
BOLT-SOCKET (Ref # 120)	120Z06125	1
BOLT-SOCKET (Ref # 120A)	120Z0614	1
BOLT-SOCKET (Ref # 120B)	120Z0622	1
BOLT-SOCKET (Ref # 120C)	120Z0625	1
BOLT-SOCKET (Ref # 120D)	120Z0630	1
BOLT-SOCKET (Ref # 120E)	120Z0635	1
BOLT-SOCKET (Ref # 120F)	120Z0640	1
BOLT-SOCKET (Ref # 120G)	120Z0670	1

## 1987 PARTS LIST

Engine Cover

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X55 (Ref # 130)	130G0655	1
SCREW-PAN-CROS,6X20,WHITE (Ref # 220)	220B0620	1
SCREW-PAN-CROS,6X28 (Ref # 220A)	220B0628	1
SCREW-PAN-CROS,6X40 (Ref # 220B)	220B0640	1