


2009 Vulcan® 1700 Nomad™ PARTS DIAGRAM

Air Cleaner



2009 Vulcan® 1700 Nomad™ PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
BOLT-SOCKET,5X12 (Ref # 120)	120CA0512	1
BOLT-SOCKET,6X25 (Ref # 120A)	120CA0625	1
BOLT-SOCKET,5X25 (Ref # 120B)	120R0525	1
W-PLAIN-S,5MM (Ref # 410)	410S0500	1
CASE-AIR FILTER (Ref # 11011)	11011-0119	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-0031	1
CASE-ASSY-AIR FILTER,LH (Ref # 11038)	11038-0022	1
CASE-ASSY-AIR FILTER,RH (Ref # 11038A)	11038-0023	1
GASKET,3X812 (Ref # 11061)	11061-0346	1
GASKET,3X630 (Ref # 11061A)	11061-0347	1
GASKET,3X222 (Ref # 11061B)	11061-0367	1
DUCT,INTAKE (Ref # 14073)	14073-0202	1
DUCT,THROBO. FUNNEL (Ref # 14073A)	14073-0203	1
VALVE,AIR SWITCHING (Ref # 16126)	16126-1437	1
WASHER,6.5X20X1.6 (Ref # 92022)	92022-1557	1
CLAMP,14.5MM (Ref # 92037)	92037-1900	1
GROMMET,AIR SUCTION VALVE (Ref # 92071)	92071-1249	1
DAMPER,RUBBER (Ref # 92075)	92075-1123	1
BOLT,6X18 (Ref # 92150)	92150-1645	1
COLLAR,6.3X10X12 (Ref # 92152)	92152-0694	1
BOLT,SOCKET,5X10 (Ref # 92154)	92154-0131	1
DAMPER (Ref # 92161)	92161-0309	1
TUBE (Ref # 92191)	92191-1704	1
TUBE,BREATHER (Ref # 92192)	92192-0650	1
TUBE,FR HEAD-ASWV (Ref # 92192B)	92192-0652	1
TUBE,RR HEAD-ASWV (Ref # 92192C)	92192-0653	1
FITTING (Ref # 92005)	92005-0054	1
TUBE,A/C-ASWV (Ref # 92192A)	92192-0651	1
TUBE,ASWV-FITTING (Ref # 92192D)	92192-0654	1

2009 Vulcan® 1700 Nomad™ PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
TUBE,FITTING-A/C (Ref # 92192E)	92192-0655	1