


# 2004 Eliminator 125 PARTS DIAGRAM

Air Cleaner(CN,US)

E1130



## 2004 Eliminator 125 PARTS LIST

Air Cleaner(CN,US)

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-1719	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1268	1
BRACKET (Ref # 11050)	11050-1427	1
GASKET,AIR FILTER (Ref # 11060)	11060-1808	1
CAP,BREATHER (Ref # 11065)	11065-1088	1
PLATE,ELEMENT (Ref # 13271)	13271-1103	1
BREATHER (Ref # 14069)	14069-1064	1
DUCT,CARBURETOR (Ref # 14073)	14073-1702	1
DUCT,INTAKE (Ref # 14073A)	14073-1703	1
COVER,INTAKE DUCT (Ref # 14090)	14090-1891	1
COVER,AIR FILTER (Ref # 14091)	14091-1114	1
VALVE (Ref # 16126)	16126-1353	1
TUBE-ASSY,DRAIN (Ref # 51044)	51044-1196	1
ARRESTER-FLAME (Ref # 59006)	59006-1057	1
FITTING,TUBE,T-TYPE (Ref # 92005)	92005-1017	1
FITTING (Ref # 92005A)	92005-1247	1
SCREW,6X16 (Ref # 92009)	92009-1621	3
SCREW,6X18 (Ref # 92009A)	92009-1830	5
SCREW,TAPPING 5X10 (Ref # 92009B)	92009-1831	5
COLLAR (Ref # 92027)	92027-1757	3
CLAMP (Ref # 92037)	92037-1610	4
CLAMP,BREATHER TUBE (Ref # 92037A)	92037-192	1
TUBE,4X9X260 (Ref # 92059)	92059-1712	1
DAMPER,VALVE (Ref # 92160)	92160-1867	1
CLAMP (Ref # 92170)	92170-1017	1
CLAMP,TUBE (Ref # 92170A)	92170-1445	2
CLAMP (Ref # 92170B)	92170-1695	1
CLAMP (Ref # 92170C)	92170-1786	1
CLAMP (Ref # 92170D)	92170-1796	3

## 2004 Eliminator 125 PARTS LIST

Air Cleaner(CN,US)

ITEM NAME	PART NUMBER	QUANTITY
CLAMP (Ref # 92170E)	92170-1845	1
CLAMP (Ref # 92170F)	92170-1864	1
TUBE,BREATHER (Ref # 92191)	92191-1162	1
TUBE,AIR FILTER-VALVE (Ref # 92191A)	92191-1163	1
TUBE,VALVE-ENGINE (Ref # 92191B)	92191-1164	1
TUBE,BREATHER (Ref # 92191C)	92191-1208	1
TUBE,L=115 (Ref # 92191D)	92191-1210	1
TUBE,7X12X45 (Ref # 92191E)	92191-1241	1