


2011 W800 (European)

PARTS DIAGRAM

Rear Hub



2011 W800 (European)

PARTS LIST

Rear Hub

ITEM NAME	PART NUMBER	QUANTITY
PIN-COTTER,4.0X35 (Ref # 550)	550AA4035	1
BEARING-BALL,#6205G (Ref # 601)	601B6205G	1
BEARING-BALL,#6303UG (Ref # 601A)	601B6303UG	2
DRUM-ASSY,REAR BRAKE,SILVER (Ref # 41034A)	41034-0070-458	1
PANEL-ASSY-BRAKE (Ref # 41035)	41035-0087	1
SHOE-BRAKE (Ref # 41048)	41048-1130	2
CAM-BRAKE (Ref # 41050)	41050-1065	1
SEAL,BRAKE CAM (Ref # 41051)	41051-003	1
LEVER-BRAKE CAM (Ref # 41053)	41053-1093	1
AXLE,RR,16X267 (Ref # 41068)	41068-0088	1
INDICATOR (Ref # 41085)	41085-1060	1
SPRING,BRAKE SHOE (Ref # 42020)	42020-004	2
COUPLING-ASSY,RR HUB (Ref # 42033A)	42033-0052	1
SLEEVE,RR AXLE,L=22 (Ref # 42036)	42036-1233	1
SPROCKET-HUB,37T (Ref # 42041)	42041-0093	1
WASHER,17.3X32X3.2 (Ref # 42046)	42046-009	1
STUD,10X19 (Ref # 92004)	92004-0028	6
COLLAR,L=104 (Ref # 92027)	92027-1714	1
COLLAR,RR HUB (Ref # 92027A)	92027-1784	1
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
RING-SNAP,52MM (Ref # 92033A)	92033-1043	1
SEAL-OIL (Ref # 92049)	92049-1287	1
CHAIN,DRIVE,EK520MVXLX104L (Ref # 92057)	92057-0213	1
JOINT-CHAIN,DRIVE (Ref # 92058)	92058-0021	1
BOLT,8X27 (Ref # 92150)	92150-1797	1
COLLAR,17.2X30X9.5 (Ref # 92152)	92152-0916	1
DAMPER,SHOCK,RR HUB (Ref # 92160)	92160-1524	1
NUT,LOCK,FLANGED,10MM (Ref # 92210)	92210-0276	6
NUT,CASTLE,16MM (Ref # 92210A)	92210-1171	1