


1987 EX500 PARTS DIAGRAM

Air Cleaner

E1130-0236



1987 EX500 PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
CASE-AIR FILTER (Ref # 11011)	11011-1245	1
CASE-AIR FILTER (Ref # 11011A)	11011-1246	1
CASE-AIR FILTER (Ref # 11011B)	11011-1247	1
CASE-AIR FILTER (Ref # 11011D)	11011-1268	1
CASE-AIR FILTER (Ref # 11011F)	11011-1269	1
CASE-AIR FILTER (Ref # 11011H)	11011-1270	1
CAP,AIR FILTER CASE,UPP (Ref # 11012)	11012-1571	1
CAP,AIR FILTER,LH (Ref # 11012A)	11012-1572	1
CAP,AIR FILTER,RH (Ref # 11012B)	11012-1573	1
CAP,AIR FILTER,LH (Ref # 11012D)	11012-1608	1
CAP,AIR FILTER,RH (Ref # 11012F)	11012-1609	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1155	1
DUCT,CARBURATOR (Ref # 14073)	14073-1292	1
DUCT,INTAKE (Ref # 14073A)	14073-1293	1
DUCT (Ref # 14073B)	14073-1295	1
VALVE,AIR SWITCH (Ref # 16126)	16126-1005	1
SCREW,TAPPING,5X25 (Ref # 92009)	92009-1339	3
SCREW,TAPPING,5X30 (Ref # 92009D)	92009-1488	3
CLAMP,TUBE (Ref # 92037)	92037-1076	1
CLAMP (Ref # 92037A)	92037-1712	1
CLAMP,TUBE (Ref # 92037B)	92037-213	1
TUBE,4X9X290 (Ref # 92059)	92059-1043	1
TUBE,4X9X110 (Ref # 92059A)	92059-1131	1
TUBE,AIR FILTER-ACV (Ref # 92059B)	92059-1770	1
TUBE,AIR SWITCH,LH (Ref # 92059C)	92059-1771	1
TUBE,AIR SWITCH,RH (Ref # 92059D)	92059-1772	1
TUBE,BREATHER (Ref # 92059E)	92059-1773	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1028	1
GROMMET,AIR FILTER (Ref # 92071A)	92071-1114	1

1987 EX500 PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
SPRING,COIL,BLACK (Ref # 92081)	92081-1457	1
SEAL,AIR FILTER CAP (Ref # 92093)	92093-1233	1
SEAL,AIR FILTER (Ref # 92093A)	92093-1234	1
SCREW-PAN-CROS,6X16 (Ref # 220)	220B0616	1
TUBE-RUBBER,5X350 (Ref # 702)	702A05350	1