


1988 EX500 PARTS DIAGRAM

Rear Wheel/Chain

F2240-0203



1988 EX500 PARTS LIST

Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
PANEL-ASSY-BRAKE,RR (Ref # 41035)	41035-1230	1
SHOE-BRAKE (Ref # 41048)	41048-020	2
CAM-BRAKE (Ref # 41050)	41050-1065	1
LEVER-BRAKE CAM (Ref # 41053)	42029-039	1
AXLE,RR (Ref # 41068)	42031-053	1
WHEEL-ASSY,RR,SILVER NO.1 (Ref # 41073A)	41073-1359-V5	1
INDICATOR,BRAKE SHOE (Ref # 41085)	41085-004	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1114	1
SLEEVE,RR HUB,L=33 (Ref # 42036)	42036-1146	1
SPROCKET-HUB,42T (Ref # 42041)	42041-1279	1
STUD,10X24 (Ref # 92004)	92004-1146	6
NUT,CASTLE,16MM (Ref # 92015)	42045-014	1
NUT,FLANGED,10MM (Ref # 92015A)	92015-1502	6
COLLAR,REAR AXLE,RH,L=18.5 (Ref # 92027)	92027-1484	1
COLLAR,REAR BRAKE DRUM,L=90 (Ref # 92027A)	92027-1772	1
COLLAR,RR HUB (Ref # 92027B)	92027-1784	1
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
RING-SNAP,52MM (Ref # 92033A)	92033-1043	1
SEAL-OIL,TWC35527 (Ref # 92049)	92052-006	1
CHAIN,DRIVE,EK520SX-OX104L (Ref # 92057)	92057-1228	1
DAMPER,SHOCK,RR HUB (Ref # 92075)	92075-1687	1
SPRING,BRAKE SHOE (Ref # 92081)	42020-004	2
SEAL,BRAKE CAM (Ref # 92093)	41051-003	1
BOLT-SMALL,8X28 (Ref # 114)	114G0828	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING-BALL,#6205G (Ref # 601)	601B6205G	1
BEARING-BALL,#6303ZZC3 (Ref # 601A)	601B6303ZZ	2