


1988 EX500

PARTS DIAGRAM

Front Fork

F2340-0288



1988 EX500

PARTS LIST

Front Fork

ITEM NAME	PART NUMBER	QUANTITY
GASKET,FORK CYLINDER BOLT (Ref # 11009)	44045-051	2
GASKET,DRAIN PLUG (Ref # 11009A)	44045-052	2
FORK-FRONT (Ref # 44001)	44001-1652	1
PIPE-LEFT FORK OUTER (Ref # 44005)	44005-1261	1
PIPE-RIGHT FORK OUTER (Ref # 44006)	44006-1258	1
PIPE-FORK INNER (Ref # 44013)	44013-1262	2
CYLINDER-COMP-FORK (Ref # 44023)	44023-1058	2
SPRING-FRONT FORK (Ref # 44026)	44026-1366	2
SEAT-FORK SPRING (Ref # 44029)	44029-1124	2
HOLDER-FORK UNDER (Ref # 44037)	44037-1212	1
HOLDER-FORK UPPER (Ref # 44039)	44039-1161	1
BUSHING-FRONT FORK (Ref # 44065)	44065-1068	2
BUSHING-FRONT FORK,INNER PIPE (Ref # 44065A)	44065-1069	2
BOLT,10X40 (Ref # 92001)	92001-1454	2
BOLT,FORK CYLINDER (Ref # 92001A)	92001-1464	2
BOLT,FLANGED,8X50 (Ref # 92002)	92002-1159	1
BOLT (Ref # 92002A)	92002-1812	2
NUT,FLANGED,8MM (Ref # 92015)	92015-1408	1
WASHER,SPRING,8MM (Ref # 92022A)	92022-1703	2
WASHER,SPRING,10MM (Ref # 92022B)	92022-1704	2
WASHER,30.5X50X0.6 (Ref # 92022C)	92022-231	1
SPACER,FORK (Ref # 92026)	92026-1038	2
RING-SNAP,FORK (Ref # 92033)	92033-1219	2
RING-SNAP,FORK TOP (Ref # 92033A)	92033-1220	2
RACE,STEERING STEM BEARING (Ref # 92048)	92047-012	1
SEAL-OIL,FORK (Ref # 92049)	92049-1226	2
SEAL-OIL,STEERING STEM (Ref # 92049A)	92056-003	1
RING-O,FORK SPRING SEAT (Ref # 92055)	92055-1359	2
SEAL,FORK (Ref # 92093)	92093-1196	2

1988 EX500

PARTS LIST

Front Fork

ITEM NAME	PART NUMBER	QUANTITY
BOLT,6X8 (Ref # 110)	110B0608	2