


2000 Ultra 150 PARTS DIAGRAM

Crankshaft/Piston(s)

E1320



2000 Ultra 150 PARTS LIST

Crankshaft/Piston(s)

ITEM NAME	PART NUMBER	QUANTITY
PIN-DOWEL (Ref # 551)	551R0612	2
PISTON-ENGINE (Ref # 13001)	13001-3731	3
PIN-PISTON (Ref # 13002)	13002-3707	3
RING-SET-PISTON,STD (Ref # 13008)	13008-3708	3
CRANKSHAFT-COMP (Ref # 13031)	13031-3738	1
BEARING-SMALL END (Ref # 13033)	13033-3704	3
BALANCER,RR (Ref # 13041)	13041-3702	1
BALANCER,FR (Ref # 13041A)	13041-3703	1
COUPLING (Ref # 42034)	42034-3711	1
GEAR-SPUR (Ref # 59051)	59051-3704	1
GEAR-SPUR,FR (Ref # 59051A)	59051-3705	1
RING-SNAP (Ref # 92033)	92033-3729	6
BEARING-BALL,TMB204C4 (Ref # 92045)	92045-3728	4
SEAL-OIL,FW7357210ZS (Ref # 92049)	92049-3725	1
SEAL-OIL,FWJ7358069ZS (Ref # 92049A)	92049-3728	1
SEAL-OIL (Ref # 92049C)	92049-3730	1
RING-O,20.8X2.4 (Ref # 92055)	92055-3740	1
COLLAR,CRANKSHAFT,RR (Ref # 92152)	92152-3701	1