


1980 KZ750-E1

PARTS DIAGRAM

CHASSIS ELECTRICAL EQUIPMENT ('80 KZY 50



1980 KZ750-E1

PARTS LIST

CHASSIS ELECTRICAL EQUIPMENT ('80 KZY 50

ITEM NAME	PART NUMBER	QUANTITY
RELAY-TURN SIGNAL (Ref # 1)	27002-011	1
RELAY,TURN SIGNAL (Ref # 2)	27002-016	1
HORN (Ref # 3)	27003-076	1
BOLT-SMALL-UPSET,8X16 (Ref # 4)	115G0816	2
WASHER SPRING 8MM (Ref # 5)	461F0800	2
WIRING HARNESS,MAIN (Ref # 6)	26001-1152	1
WIRING HARNESS,CENTER (Ref # 7)	26001-1117	1
FUSE ASSY (Ref # 8)	26004-1006	1
DAMPER RUBBER,FUSE (Ref # 9)	92075-279	1
FUSE-20A (Ref # 10)	26006-005	2
FUSE 10A (Ref # 11)	26006-003	3
LEAD WIRE,SIGNAL LAMP (Ref # 12)	26011-063	3
WIRE,LEAD,BATTERY(-) (Ref # 13)	26011-1032	1
WIRE,LEAD,BATTERY GRD (Ref # 14)	26011-1080	1
WASHER SPRING 6MM (Ref # 15)	461F0600	1
BOLT,HEX HEAD,6MM (Ref # 16)	92001-137	1
BAND,SHORT (Ref # 17)	92072-030	4
BAND,MIDDLE (Ref # 18)	92072-031	1
BAND,WIRING HARNESS (Ref # 19)	92072-056	4
FB BAT FB12A-A (Ref # 20)	26012-1004	1
LABEL-WARNING,BATTERY (Ref # 21)	56040-1036	1
CLAMP,HARNESS (Ref # 22)	92037-113	1