


1984 KDX250

PARTS DIAGRAM

KICKSTARTER MECHANISM

E1340-0041



1984 KDX250

PARTS LIST

KICKSTARTER MECHANISM

ITEM NAME	PART NUMBER	QUANTITY
BOSS,KICK PEDAL (Ref # 13061A)	13061-1107	1
LEVER-ASSY-KICK,PEDAL (Ref # 13064A)	13064-1103	1
SHAFT-KICK (Ref # 13066)	13066-1026	1
GUIDE,KICK SPRING (Ref # 13070)	13070-1063	1
RATCHET (Ref # 13078)	13078-1061	1
GUIDE-KICK (Ref # 13206)	13206-1059	1
STOPPER,KICKSTARTER (Ref # 32085)	32085-1016	1
IDLE GEAR, KICKSTRTER (Ref # 59051)	59051-1022	1
GEAR-SPUR,KICKSTARTER (Ref # 59051A)	59051-1051	1
NUT,12MM (Ref # 92015)	92015-1001	1
WASHER,3X6,5X0.8 (Ref # 92022A)	92022-1481	1
WASHER (Ref # 92022B)	92022-252	2
WASHER,PLAIN (Ref # 92022C)	92022-269	1
WASHER,PLAIN (Ref # 92022D)	92022-271	3
WASHER,PLAIN (Ref # 92022E)	92022-315	1
CIRCLIP,18MM (Ref # 92033)	92033-029	1
SPRING KICK PEDAL (Ref # 92081)	92081-020	1
SPRING,RATCHET (Ref # 92081A)	92081-122	1
SPRING,KICKSTARTER (Ref # 92081B)	92081-1253	1
BOLT-UPSET (Ref # 112)	112G0618	2
SCREW-SET-SOCKET (Ref # 290)	290Q0814	1
CIRCLIP 15MM (Ref # 480)	480J1500	1
CIRCLIP 16MM (Ref # 480A)	480J1600	1
CIRCLIP 18MM (Ref # 480B)	480J1800	1
BALL STEEL 1/4' (Ref # 600)	600A0800	1
"O" RING,4MM (Ref # 670)	670B1504	1