

1983 KDX250


PARTS DIAGRAM

SWING ARM

Kawasaki

Let the Good Times Roll®

F2141-0007



1983 KDX250

PARTS LIST SWING ARM

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1207	4
GUIDE,CHAIN,REAR (Ref # 12053)	12053-1011	1
GUIDE,CHAIN,REAR (Ref # 12053A)	12053-1039	1
GUIDE-CHAIN,FR (Ref # 12053B)	12053-1068	1
GUIDE-CHAIN,RR (Ref # 12053C)	12053-1073	2
ARM-COMP-SWING (Ref # 33001)	33001-1175	1
SHAFT-SWING ARM (Ref # 33032)	33032-1042	1
ADJUSTER-CHAIN,LH (Ref # 33040)	33040-1060	2
SLEEVE,SWING ARM (Ref # 42036)	42036-1056	2
SCREW,6X10 (Ref # 92009)	92009-1286	2
SCREW,6X14 (Ref # 92009A)	92009-1287	1
NUT,14MM (Ref # 92015)	92015-1407	1
NUT-6MM (Ref # 92015A)	92015-1078	2
SHIM,SWING ARM (Ref # 92025)	92025-1116	4
PIN (Ref # 92043)	92043-1110	2
BRG,NEEDLE,HMK2030 (Ref # 92046)	92046-1031	2
BOLT,FLANGED,6X35 (Ref # 130)	130H0635	2
PIN COTTER 2.0X15 (Ref # 550)	550D2015	2