


1983 KX250 PARTS DIAGRAM

KICKSTARTER MECHANISM ('83 KX250-C1)



L1340-0034



1983 KX250 PARTS LIST

KICKSTARTER MECHANISM ('83 KX250-C1)

ITEM NAME	PART NUMBER	QUANTITY
BOSS,KICK PEDAL (Ref # 13061)	13061-1055	1
LEVER-ASSY-KICK,PEAL (Ref # 13064)	13064-1038	1
SHAFT-KICK (Ref # 13066)	13066-1026	1
GUID,KICKSTARTER SPRG (Ref # 13070)	13070-011	1
RATCHET (Ref # 13078)	13078-1061	1
IDLE GEAR, KICKSTRTER (Ref # 59051)	59051-1022	1
GEAR-SPUR,KICKSTARTER (Ref # 59051A)	59051-1051	1
NUT,12MM (Ref # 92015)	92015-1001	1
WASHER,PLAIN (Ref # 92022)	92022-1019	1
WASHER (Ref # 92022A)	92022-252	2
WASHER,PLAIN (Ref # 92022B)	92022-269	1
WASHER,PLAIN (Ref # 92022C)	92022-271	3
WASHER,PLAIN (Ref # 92022D)	92022-315	1
CIRCLIP,18MM (Ref # 92033)	92033-029	1
"O" RING,11.5MM (Ref # 92055)	92055-072	2
SPRING KICK PEDAL (Ref # 92081)	92081-020	1
SPRING,RATCHET (Ref # 92081A)	92081-122	1
SPRING,KICKSTARTER (Ref # 92081B)	92081-1253	1
SCREW, 8X16 (Ref # 290)	290Q0816	1
CIRCLIP 16MM (Ref # 480)	480J1600	1
CIRCLIP 18MM (Ref # 480A)	480J1800	1
CIR CLIP (Ref # 482)	482K0100	1
BALL STEEL 1/4' (Ref # 600)	600A0800	1