


1983 LTD Belt

PARTS DIAGRAM

KICKSTARTER MECHANISM

Kawasaki
Let the Good Times Roll®

E1340-0014



1983 LTD Belt

PARTS LIST

KICKSTARTER MECHANISM

ITEM NAME	PART NUMBER	QUANTITY
CAP,KICKSTARTER (Ref # 11012)	92102-008	1
PEDAL ASSY,KICK (Ref # 13059)	13058-061	1
BOSS-KICK PEDAL (Ref # 13061)	13061-010	1
SHAFT,KICKSTARTER (Ref # 13066)	13066-1004	1
GUID,KICK SPRING (Ref # 13070)	13070-1008	1
RATCHET,KICK SHAFT (Ref # 13078)	13078-011	1
STOPPER,KICKSTARTER (Ref # 32085)	13072-012	1
GEAR,KICKSTARTER (Ref # 59051)	59051-1005	1
BOLT-KICK PEDAL (Ref # 92001)	92001-110	1
WASHER,PLAIN,22MM (Ref # 92022)	92022-207	2
COLLAR,KICKSHAFT (Ref # 92028)	92028-126	1
CIRCLIP,25MM (Ref # 92033)	92033-025	1
PIN-KICK PEDAL (Ref # 92043)	92043-081	1
RUBBER KICK PEDAL (Ref # 92075)	13063-004	1
SPRING KICK PEDAL (Ref # 92081)	92081-020	1
SPRING RATCHET (Ref # 92081A)	92081-104	1
SPRING,KICKSTARTER (Ref # 92081B)	92082-004	1
BOLT-UPSET (Ref # 110)	112G0614	2
WASHER PLAIN 8MM (Ref # 410)	410B0800	1
CIRCLIP,19MM (Ref # 480)	480J1900	1
CIRCLIP,22MM (Ref # 480A)	480J2200	1
CIRCLIP 5MM (Ref # 482)	482K5000	1
BALL STEEL 1/4" (Ref # 600)	600A0800	1