



# 1986 Eliminator PARTS LIST

## ROCKER ARMS/VALVES

ITEM NAME	PART NUMBER	QUANTITY
VALVE-INTAKE (Ref # 12004)	12004-1085	8
VALVE-EXHAUST (Ref # 12005)	12005-1052	8
RETAINER-VALVE SPRING (Ref # 12009)	12009-1054	16
SPLIT KEEPER,VALVE SP (Ref # 12011)	12011-1003	32
ARM-ROCKER (Ref # 12016)	12016-1051	8
SHAFT-ROCKER,L=343 (Ref # 12020)	12020-1051	2
SEAT-SPRING (Ref # 16007)	16007-1144	16
SEAT-SPRING (Ref # 16007A)	16007-1143	16
SPRING-ENGINE VALVE,I (Ref # 49078)	49078-1067	16
SPRING-ENGINE VALVE,O (Ref # 49078A)	49078-1068	16
SCREW,7MM (Ref # 92009)	92009-1279	16
NUT,7MM (Ref # 92015)	92015-1325	16
SEAL-OIL,RVC2-5.5X8.5 (Ref # 92049)	92049-1062	16
PLUG,14X11.5 (Ref # 92066)	92066-1192	2
SPRING,ROCKER ARM (Ref # 92081)	92081-1636	8
"O" RING,15MM (Ref # 670)	670B2015	2