


1986 Eliminator

PARTS DIAGRAM

FRONT FORK



1986 Eliminator

PARTS LIST FRONT FORK

ITEM NAME	PART NUMBER	QUANTITY
GASKET,FORK DRAIN PLG (Ref # 11009)	44045-046	2
GASKET,FORK CYL BOLT (Ref # 11009A)	44045-051	2
CAP,FORK TOP (Ref # 11012)	11012-1473	2
VALVE,AIR (Ref # 16126)	16126-1105	2
FORK-FRONT (Ref # 44001A)	44001-1640	1
PIPE-LEFT FORK OUTER (Ref # 44005)	44005-1233	1
PIPE-RIGHT FORK OUTER (Ref # 44006)	44006-1233	1
PIPE-FORK INNER (Ref # 44013)	44013-1232	2
CYLINDER-FORK (Ref # 44022)	44022-1182	2
SPRING-FRONT FORK,K=0 (Ref # 44026)	44026-1303	2
SEAT-FORK SPRING (Ref # 44029)	44029-1120	2
HOLDER-FORK UNDER (Ref # 44037)	44037-1183	1
HOLDER-FORK UPPER (Ref # 44039A)	44039-1129	1
BUSHING-FRONT FORK (Ref # 44065)	44065-1070	2
BUSHING-FRONT FORK,IN (Ref # 44065A)	44065-1071	2
LABEL-WARNING,AIR SUS (Ref # 56040)	56040-1054	1
BOLT,HEX HEAD,8X40 (Ref # 92001)	92001-1063	4
BOLT,FORK DRAIN (Ref # 92001A)	92001-1464	2
BOLT,FLANGED,8X50 (Ref # 92001B)	92001-1486	1
BOLT (Ref # 92002)	92002-1603	2
NUT,8MM (Ref # 92015)	92015-1055	1
WASHER,SPRING,8MM (Ref # 92022)	92022-1703	6
SPACER,FORK (Ref # 92026)	92026-1254	2
RING-SNAP,FORK (Ref # 92033)	92033-1200	2
RING-SNAP (Ref # 92033A)	92033-1201	2
SEAL-OIL,FORK (Ref # 92049)	92049-1230	2
RING-O,FORK SPRING SE (Ref # 92055)	92055-1309	2
SEAL,FORK (Ref # 92093)	92093-1197	2
SCREW PAN HEAD 4X6 (Ref # 220)	220B0406	2