


1985 LTD Shaft

PARTS DIAGRAM

AIR CLEANER

E1130-0183



1985 LTD Shaft

PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
GASKET,AIR FILTER (Ref # 11009)	11009-1403	1
FILTER-ASSY-AIR (Ref # 11010)	11010-1224	1
ELEMENT,AIR CLNR (Ref # 11013)	11013-1040	1
BRACKET-A,FILTER CASE (Ref # 11036)	11036-1456	1
BRACKET-A,SILENCER (Ref # 11036A)	11036-1458	1
BRACKET,AIR FILTER,UP (Ref # 11043)	11043-1554	1
COVER,INTAKE SILENCER (Ref # 14025)	14025-1846	1
COVER,INTAKE SILENCER (Ref # 14025A)	14025-1847	1
DUCT,AIR FILTER,OUTLE (Ref # 14073)	14073-1048	4
DUCT,AIR FILTER (Ref # 14073A)	14073-1173	1
VALVE ASSY,AIR SWITCH (Ref # 16126)	16126-1014	1
SILENCER (Ref # 39162)	39162-1003	1
SILENCER-INTAKE (Ref # 39162A)	39162-1053	1
SILENCER-INTAKE (Ref # 39162B)	39162-1055	1
FITTING,TUBE (Ref # 92005)	92005-1017	1
SCREW,TAPPING,5X12 (Ref # 92009)	92009-1319	2
CLAMP FUEL PIPE (Ref # 92037)	92037-010	2
CLAMP-PIPE (Ref # 92037A)	92037-072	6
CLAMP (Ref # 92037B)	92037-1076	1
CLAMP,BREATHER TUBE (Ref # 92037C)	92037-213	4
TUBE,VACUUM,LONG (Ref # 92059)	92059-1162	2
TUBE,VACUUM,LONG (Ref # 92059A)	92059-1162	1
TUBE,14X20X89 (Ref # 92059B)	92059-1155	2
TUBE,AIR FILTER (Ref # 92059C)	92059-1156	2
TUBE,14X20X340 (Ref # 92059D)	92059-1171	1
PLUG,DRAIN,AIR FILTER (Ref # 92066)	92066-1121	1
PLUG (Ref # 92066A)	92074-027	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1042	1
GROMMET,AIR FILTER (Ref # 92071A)	92071-1112	1

1985 LTD Shaft

PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
DAMPER,SILENCER DRAIN (Ref # 92075)	92075-1632	2
DAMPER,AIR FILTER COV (Ref # 92075A)	92075-1658	2
SPRING,COIL,BLACK (Ref # 92081)	92081-1457	4
BOLT (Ref # 130)	130B0614	1
SCREW-PAN-WP-CROS (Ref # 224)	224B0514	3
TUBE-RUBBER 5X400 (Ref # 702)	702A05400	1