


1985 Tecate PARTS DIAGRAM

CRANKCASE ('85 A2)



1985 Tecate PARTS LIST

CRANKCASE ('85 A2)

| ITEM NAME | PART NUMBER | QUANTITY |
|--------------------------------------|-------------|----------|
| GASKET CHECK VALVE (Ref # 11009) | 92065-058 | 1 |
| GUIDE-KICK (Ref # 13206) | 13206-1052 | 1 |
| SET-CRANKCASE (Ref # 14001) | 14001-5152 | 1 |
| BREATHER (Ref # 14069) | 14069-003 | 1 |
| STOPPER,KICKSTARTER (Ref # 32085) | 32085-1016 | 1 |
| BOLT,W/WASHER,6X14 (Ref # 92001) | 92001-1829 | 4 |
| STUD,10X35 (Ref # 92004) | 92004-1063 | 2 |
| STUD,10X45 (Ref # 92004A) | 92004-1065 | 2 |
| BUSHING,CRANKCASE (Ref # 92028) | 92028-1133 | 4 |
| BUSHING (Ref # 92028A) | 92028-131 | 1 |
| BUSHING (Ref # 92028B) | 92028-132 | 1 |
| CLAMP FUEL PIPE (Ref # 92037) | 92037-010 | 1 |
| CLAMP,HARNESS (Ref # 92037A) | 92037-1318 | 1 |
| PIN-DOWEL (Ref # 92043) | 92042-007 | 2 |
| PIN,CHANGE PEDAL (Ref # 92043A) | 92043-1055 | 1 |
| BEARING-BALL (Ref # 92045) | 92045-1211 | 1 |
| BEARING BALL #6305SH2 (Ref # 92045A) | 92045-1024 | 2 |
| BEARING-BALL,6905Z (Ref # 92045B) | 92045-1058 | 1 |
| BEARING-BALL,6205 (Ref # 92045C) | 92045-1115 | 1 |
| OIL SEAL,TCJ25457 (Ref # 92049) | 92049-1051 | 1 |
| OIL SEAL,TCJ20407 (Ref # 92049A) | 92049-1052 | 1 |
| OIL SEAL TB3040 (Ref # 92049B) | 92050-033 | 1 |
| OIL SEAL,TB13225.5 (Ref # 92049C) | 92051-005 | 1 |
| TUBE,6X9X750 (Ref # 92059) | 92059-1372 | 1 |
| PLUG OIL DRAIN (Ref # 92066) | 92067-001 | 1 |
| BOLT-UPSET (Ref # 112) | 112G0618 | 2 |
| BOLT-FLANGED-SMALL (Ref # 132) | 132G0640 | 12 |
| BEARING BALL #6204 (Ref # 601) | 601B6204 | 1 |