


# 1986 KLT110

## PARTS DIAGRAM

### CLUTCH

E1350-0077



# 1986 KLT110

## PARTS LIST

### CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
CAP,CLUTCH COVER (Ref # 11012)	11012-1294	1
CLUTCH-ASSY (Ref # 13081)	13081-1097	1
WHEEL-CLUTCH (Ref # 13086)	13086-1011	1
PLATE-FRICTION (Ref # 13088)	13088-1017	3
PLATE-CLUTCH (Ref # 13089)	13089-1008	1
PLATE-CLUTCH (Ref # 13089A)	13089-1013	1
PLATE-CLUTCH (Ref # 13089B)	13089-1014	1
PLATE-CLUTCH (Ref # 13089C)	13089-1015	1
PLATE-CLUTCH (Ref # 13089D)	13089-1016	1
HOUSING-CLUTCH (Ref # 13096)	13096-1032	1
GEAR-PRIMARY SPUR (Ref # 13097)	13097-1086	1
RELEASE-COMP-CLUTCH (Ref # 13102A)	13102-1073	1
PUSHER-CLUTCH (Ref # 13114A)	13114-1054	1
CAM-RELEASE,CLUTCH (Ref # 13119A)	13119-1056	1
GEAR-COMP,CLUTCH (Ref # 13216)	13216-1040	1
BOLT,CLUTCH RELEASE (Ref # 92001)	92001-1906	1
NUT,8M/M (Ref # 92015)	92015-1136	1
NUT,FLANGED,14MM (Ref # 92015A)	92015-1341	1
WASHER,5.2X17X1 (Ref # 92022)	92022-1312	3
SPACER,18.5X30X1.6 (Ref # 92026)	92026-1082	1
SPACER,L=19 (Ref # 92026A)	92026-1130	1
COLLAR,14X15X7.5 (Ref # 92027)	92027-1442	3
RING-SNAP (Ref # 92033)	92033-1059	1
RING-SNAP,46MM (Ref # 92033A)	92033-1101	1
RETAINER,CLUTCH RELEA (Ref # 92045A)	14020-1092	1
SPRING,CLUTCH PLATE (Ref # 92081)	92081-1527	3
SPRING,COIL (Ref # 92081A)	92081-1566	1
SPRING,CONICAL (Ref # 92081B)	92081-1629	1
BUSHING-RUBBER,10.5X1 (Ref # 92092)	92092-1017	3

# 1986 KLT110

## PARTS LIST

### CLUTCH

ITEM NAME	PART NUMBER	QUANTITY
ROLLER,4MM (Ref # 92122)	92122-1034	3
SCREW PAN HEAD 5X12 (Ref # 220A)	220B0512	3
WASHER PLAIN 8MM (Ref # 411)	411B0800	1
BEARING-BALL,#6200 (Ref # 601)	601A6200Z	1
"O" RING,8MM (Ref # 670)	670B1508	1