


1986 KLT110 PARTS DIAGRAM

REAR HUB/AXLE/BRAKE/CHAIN (KLT110-A1/A2)



1986 KLT110 PARTS LIST

REAR HUB/AXLE/BRAKE/CHAIN (KLT110-A1/A2)

ITEM NAME	PART NUMBER	QUANTITY
PLATE,RR SPROCKETT (Ref # 13169)	13169-1754	1
PLATE-SPROCKET GUIDE (Ref # 13169A)	13169-4021	1
ADJUSTER-CHAIN (Ref # 33040)	33040-4006	1
DRUM (Ref # 41038)	41038-4010	1
HOUSING,BEARING (Ref # 41046)	41046-4006	1
SHOE-BRAKE,RR (Ref # 41048)	41048-1025	2
CAM SHAFT,REAR BRAKE (Ref # 41050)	42026-026	1
LEVER-BRAKE CAM (Ref # 41053)	41053-4004	1
AXLE-ASSY (Ref # 41067)	41067-4011	1
SPROCKET-HUB (Ref # 42041)	42041-4006	1
HUB,RR (Ref # 49030A)	49030-4022-8T	2
GUARD,RR-BRAKE-DRUM (Ref # 55020)	55020-4036	1
BOLT,LUG (Ref # 92001)	92001-4006	8
NUT,14MM (Ref # 92015)	42045-020	2
NUT-6MM (Ref # 92015A)	92015-1078	1
NUT,LOCK,32MM (Ref # 92015B)	92015-1493	2
NUT,10MM (Ref # 92015C)	92015-1429	4
WASHER (Ref # 92022)	92022-1229	2
WASHER,LOCK (Ref # 92022A)	92022-4025	2
WASHER,12.5X28X4.5 (Ref # 92022B)	92022-4037	3
COLLAR,102X109X9 (Ref # 92027)	92027-1731	1
COLLAR (Ref # 92027A)	92027-4025	1
"0" RING,11MM (Ref # 92055)	92055-004	1
DR CHAIN,EK428SH 100L (Ref # 92057)	92057-4010	1
DAMPER (Ref # 92075)	92075-4034	4
SPRING,BRAKE SHOE (Ref # 92081)	92081-1550	1
SPRING,BRAKE SHOE (Ref # 92081A)	92081-1766	1
SEAL (Ref # 92093)	92093-4008	1
BOLT-UPSET,6X12 (Ref # 112)	112G0612	4

1986 KLT110 PARTS LIST

REAR HUB/AXLE/BRAKE/CHAIN (KLT110-A1/A2)

ITEM NAME	PART NUMBER	QUANTITY
1BOLT-UPSET (Ref # 112A)	112H0640	1
BOLT-FINE-WS (Ref # 160)	160H1225	4
BOLT-UPSET-WS (Ref # 180)	180D0612	4
NUT 6MM (Ref # 311)	311B0600	4
NUT 8MM (Ref # 318)	318G0800	2
WASHER PLAIN 8MM (Ref # 411)	411B0800	1
WASHER SPRING 6MM (Ref # 461)	461F0600	4
PIN,COTTER (Ref # 550)	550D3230	2
BEARING-BALL (Ref # 601)	601A6007UU	2