


# 1986 Tecate PARTS DIAGRAM

FRONT HUB

F2230-U137



# 1986 Tecate PARTS LIST

## FRONT HUB

ITEM NAME	PART NUMBER	QUANTITY
AXLE,FR (Ref # 41068)	41068-1206	1
HUB,FR (Ref # 49030)	49030-1071	1
COLLAR,L=20 (Ref # 92027)	92027-1951	2
COLLAR,40.2X45.4X129 (Ref # 92027A)	92027-1953	1
SEAL-OIL,AG1258A0 (Ref # 92049)	92049-1110	2
BOLT-STUD-FINE,10X20 (Ref # 175)	175G1020	4
RING, SNAP,43.5M/M (Ref # 481)	92033-1040	1
BEARING-BALL #6203 (Ref # 601)	601B6203ZZ	2