


1986 Ninja® 1000R

PARTS DIAGRAM

REAR WHEEL/HUB/CHAIN

1-2240-0183



1986 Ninja® 1000R

PARTS LIST

REAR WHEEL/HUB/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
AXLE,RR (Ref # 41068)	41068-1194	1
WHEEL-ASSY,RR,BLACK (Ref # 41073)	41073-1312-R2	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1117	1
SLEEVE,RR HUB,L=53 (Ref # 42036)	42036-1150	1
SPROCKET-HUB,41T (Ref # 42041)	42041-1200	1
STUD,12X27 (Ref # 92004)	92004-1155	6
NUT,12MM (Ref # 92015)	92015-1433	6
WASHER,23X32X2.3 (Ref # 92022)	92022-1618	1
COLLAR,20.2X28X96 (Ref # 92027)	92027-1660	1
COLLAR,RR AXLE,L=20 (Ref # 92027A)	92027-1792	1
COLLAR,RR AXLE,L=28 (Ref # 92027B)	92027-1810	1
COLLAR,RR AXLE,L=20.5 (Ref # 92027C)	92027-1884	1
RING,SNAP,56.2M/M (Ref # 92033)	92033-1043	1
CIRCLIP,62M/M (Ref # 92033A)	92033-1044	1
RING-SNAP,RR AXLE (Ref # 92033B)	92033-1156	2
SEAL-OIL (Ref # 92049)	92049-1061	1
OIL SEAL (Ref # 92049A)	92050-027	1
DR,CHAIN EK632UVD0 94 (Ref # 92057)	92057-1213	1
DAMPER,SHOCK,RR HUB (Ref # 92075)	92075-1593	1
BALL BEARING,#6206 (Ref # 601)	601B6206	1
BEARING,BALL,#6304ZZ (Ref # 601A)	601B6304ZZ	2