


# 1987 Ninja® 600RX PARTS DIAGRAM

## REAR WHEEL/HUB/CHAIN



# 1987 Ninja® 600RX PARTS LIST

## REAR WHEEL/HUB/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
AXLE,RR (Ref # 41068)	41068-1232	1
WHEEL-ASSY,RR,BLACK (Ref # 41073)	41073-1436-R2	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1114	1
SLEEVE,RR HUB,L=26 (Ref # 42036)	42036-1149	1
SPROCKET-HUB,39T (Ref # 42041)	42041-1287	1
STUD,10X24 (Ref # 92004)	92004-1146	6
NUT CASTLE 16M/M (Ref # 92015)	42045-014	1
NUT,FLANGED,10MM (Ref # 92015A)	92015-1502	6
COLLAR,RR AXLE,L=20 (Ref # 92027)	92027-1874	1
COLLAR,RR AXLE,L=28 (Ref # 92027A)	92027-1875	1
COLLAR,L=106 (Ref # 92027B)	92027-1876	1
CIRCLIP,47M/M (Ref # 92033)	92033-1042	1
RING,SNAP,56.2M/M (Ref # 92033A)	92033-1043	1
OIL SEAL,AG1556EO (Ref # 92049)	92049-1056	1
OIL SEAL WTC35527 (Ref # 92049A)	92052-006	1
DR CHAIN EK50KVDO 102 (Ref # 92057)	92057-1189	1
DAMPER,SHOCK,RR HUB (Ref # 92075)	92075-1687	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING BALL #6205 (Ref # 601)	601B6205	1
BEARING-BALL,#6303ZZC3 (Ref # 601A)	601B6303ZZ	2