



1987 KX250

PARTS DIAGRAM

FOOTRESTS

F2160-0158



1987 KX250

PARTS LIST

FOOTRESTS

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
BRACKET-STEP (Ref # 32054)	32054-1150	1
STEP,LH (Ref # 34028)	34028-1173	1
STEP,RH (Ref # 34028A)	34028-1174	1
WASHER,PLAIN (Ref # 92022)	92022-239	2
PIN,10X37.5 (Ref # 92043)	92043-1217	2
SPRING,STEP,LH (Ref # 92081)	92081-1606	1
SPRING,STEP,RH (Ref # 92081A)	92081-1607	1
BOLT-FLANGED,8X16 (Ref # 130)	130G0816	2
PIN,COTTER (Ref # 550)	550D2018	2