


# 1977 KD125-A3

## PARTS DIAGRAM

### KICKSTARTER MECHANISM

**Kawasaki**  
Let the Good Times Roll®



# 1977 KD125-A3

## PARTS LIST

### KICKSTARTER MECHANISM

| ITEM NAME                       | PART NUMBER | QUANTITY |
|---------------------------------|-------------|----------|
| PEDAL,KICKSTARTER (Ref # 1)     | 13064-019   |          |
| RUBBER KICK PEDAL (Ref # 2)     | 13063-002   |          |
| BOLT-SMALL-UPSET 8X25 (Ref # 3) | 115G0825    |          |
| PIN (Ref # 4)                   | 92043-102   |          |
| WASHER,PLAIN (Ref # 5)          | 92022-268   |          |
| CIRCLIP 16MM (Ref # 6)          | 480J1600    |          |
| GUIDE,KICKSPRING (Ref # 7)      | 13070-008   |          |
| SPRING,KICKSTARTER (Ref # 8)    | 92082-005   |          |
| SHAFT,KICKSTARTER (Ref # 9)     | 13066-1012  |          |
| SHAFT,KICKSTARTER (Ref # 9)     | 13066-1012  |          |
| WASHER,PLAIN (Ref # 10)         | 92022-315   |          |
| GEAR,KICKSTARTER (Ref # 11)     | 13068-032   |          |
| RATCHET,KL250-D2 (Ref # 12)     | 13078-1052  |          |
| SPRING,RATCHET (Ref # 13)       | 92081-122   |          |
| WASHER,PLAIN (Ref # 14)         | 92022-315   |          |
| WASHER,PLAIN (Ref # 15)         | 92022-269   |          |
| STOPPER,KICKSTARTER (Ref # 16)  | 32085-1061  |          |
| GUIDE,KICKSTARTER (Ref # 17)    | 13206-010   |          |
| WASHER,LOCK (Ref # 18)          | 92024-054   |          |
| BOLT-UPSET (Ref # 19)           | 112G0618    |          |