


# 1976 KX125-A3 PARTS DIAGRAM

KICKSTARTER MECHANISM ('74-'76 KX125/A/A)



# 1976 KX125-A3 PARTS LIST

KICKSTARTER MECHANISM ('74-'76 KX125/A/A)

ITEM NAME	PART NUMBER	QUANTITY
PEDAL,KICKSTARTER (Ref # 1)	13058-055	
PIN-KICKSTARTER (Ref # 2)	92043-075	
WASHER PLAIN 8MM (Ref # 3)	410B0800	
CIRCLIP 5MM (Ref # 4)	482K5000	
BOSS,KICK PEDAL (Ref # 5)	13061-022	
BALL STEEL 1/4' (Ref # 6)	600A0800	
SPRING KICK PEDAL (Ref # 7)	92081-020	
BOLT-SMALL-UPSET 8X25 (Ref # 8)	115G0825	
PIN (Ref # 9)	92043-102	
WASHER,PLAIN (Ref # 10)	92022-268	
CIRCLIP 16MM (Ref # 11)	480J1600	
GUIDE,KICKSPRING (Ref # 12)	13070-008	
SPRING,KICKSTARTER (Ref # 13)	92082-005	
SHAFT,KICKSTARTER (Ref # 14)	13066-040	
WASHER,PLAIN (Ref # 15)	92022-315	
KICK GEAR&RATCHET ASY (Ref # 16)	13250-001	
GEAR,KICKSTARTER (Ref # 16)	13068-032	
KICK GEAR&RATCHET ASY (Ref # 17)	13250-001	
RATCHET,KL250-D2 (Ref # 17)	13078-1052	
SPRING,RATCHET (Ref # 18)	92081-122	
WASHER-THRUST (Ref # 19)	92022-197	
WASHER,PLAIN (Ref # 19)	92022-315	
WASHER,PLAIN (Ref # 20)	92022-269	
STOPPER,KICKSTARTER (Ref # 21)	32085-1061	
GUIDE,KICKSTARTER (Ref # 22)	13206-010	
WASHER,LOCK (Ref # 23)	92024-054	
BOLT-UPSET (Ref # 24)	112G0618	