


1973 F7-B PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL



1973 F7-B PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET (Ref # 1)	112G0618	1
SCREW-PAN-CROS (Ref # 1)	220B0540	1
WASHER SPRING 6MM (Ref # 2)	461F0600	1
WASHER PLAIN (Ref # 2)	410F0500	1
WASHER 6.5X20X1.6T (Ref # 3)	92022-125	1
WASHER SPRING 5MM (Ref # 3)	461F0500	1
COLLAR (Ref # 4)	92027-103	1
NUT,5MM (Ref # 4)	311B0500	1
RUBBER-FOOTREST (Ref # 5)	92076-023	2
CIRCLIP 16MM (Ref # 6)	480J1600	1
SPRING FOOTREST PEG (Ref # 7)	34006-002	1
WASHER FOLDING PEG (Ref # 8)	92022-049	1
BAR ASSY,FOOTREST (Ref # 9, 10,)	34002-051	2
HOLDER-FOTREST BAR,LH (Ref # 9)	34003-030	1
BAR-FOOTREST (Ref # 9)	34003-032	1
BRACKET-FOOTREST BAR (Ref # 10)	34007-009	1
WASHER SPRING 10MM (Ref # 11)	461F1000	1
NUT 10MM (Ref # 12)	315B1000	2
NUT-LOCK,12MM (Ref # 12)	92019-009	1
PEDAL-BRAKE (Ref # 13)	43001-035	1
PEDAL-BRAKE (Ref # 13)	43001-046	2
BOLT,10X28 (Ref # 14)	113G1028	1
SPRING MAIN STAND (Ref # 16)	34023-005	1
STAND-SIDE (Ref # 17)	34024-028	1
WASHER BRAKE PEDAL (Ref # 18)	92022-085	1
SPRING,BRAKE PEDAL (Ref # 19)	43005-033	1
PIN COTTER 3.0X30 (Ref # 20)	550D3030	1
BRAKE ROD ASSY (Ref # 21~25)	43010-5003	1
ROD ASSY-BRAKE (Ref # 21~25)	43010-013	2

1973 F7-B PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
SPRING,BRAKE ROD (Ref # 23)	43012-001	2
PIN BRAKE (Ref # 24)	92043-039	2
NUT-BRAKE ROD ADJUST (Ref # 25)	92015-042	2
WASHER PLAIN 6MM (Ref # 26)	410B0600	2
PIN COTTER 2.0X15 (Ref # 27)	550D2015	2
STEP-ASSY,FR,LH (Ref # 28)	34027-1114	1
STEP-ASSY,FR,RH (Ref # 29)	34027-1115	1
HOLDER,FOTRST BAR,LH (Ref # 30)	34021-001-10	1
WASHER PL 22.5X36X2.3 (Ref # 31)	92022-204	1
PIN-FOOTREST BAR FIT (Ref # 32)	92043-080	1
PIN,COTTER,2.5X15 (Ref # 33)	550D2515	1
PIN-BRAKE ROD FITTING (Ref # 39)	92043-064	1