


1977 KE175

PARTS DIAGRAM

HANDLEBAR



1977 KE175

PARTS LIST HANDLEBAR

ITEM NAME	PART NUMBER	QUANTITY
HANDLEBAR (Ref # 1)	46004-033	
BOOTS,LEVER HOLDER (Ref # 2)	49006-1017	
LEVER FRONT BRAKE (Ref # 3)	46058-004	
BOLT,HEX HEAD,5X22 (Ref # 4)	92007-046	
HOLDER-FR BRK LEV,BLK (Ref # 5)	46060-009-21	
WASHER LOCK 5MM (Ref # 6)	464H0500	
NUT-LOCK,5MM (Ref # 7)	92019-014	
WASHER PLAIN 6MM (Ref # 8)	411B0600	
BOLT HEX HEAD 6X25 (Ref # 9)	110N0625	
NUT-LOCK (Ref # 10)	46056-005	
SCREW CABLE ADJUST (Ref # 11)	46055-003	
SWITCH-FR. BRAKE LAMP (Ref # 12)	27021-004	
GRIP ASSY,THROTTLE (Ref # 13)	46019-039	
CASE ASSY,R.H (Ref # 14)	46018-047	
HOLDER,CONTROL CABLE (Ref # 15)	46037-023	
SCREW-PAN-CROS,5X25 (Ref # 16)	220B0525	
BOOTS,LEVER HOLDER (Ref # 17)	49006-1017	
HOLDER-CLUTCH LEV,BLK (Ref # 18)	46094-011-21	
LEVER-CLUTCH (Ref # 19)	46092-015	
CASE ASSY,L.H (Ref # 20)	46091-050	
CASE ASSY,L.H (Ref # 20)	46091-052	
SCREW CNTSNK HD 3X8 (Ref # 21)	221B0308A	
KNOB-L.H SWITCH,B (Ref # 22)	46044-008	
KNOB-L.H SWITCH (Ref # 23)	46044-011	
SCREW PAN HEAD 3X5 (Ref # 24)	220B0305A	
WASHER (Ref # 25)	92095-010	
KNOB-SWITCH (Ref # 26)	46044-007	
SWITCH ASSY LH BUTTON (Ref # 27)	46078-003	
WASHER LOCK (Ref # 28)	92095-012	

1977 KE175

PARTS LIST

HANDLEBAR

Kawasaki

Let the Good Times Roll®

ITEM NAME	PART NUMBER	QUANTITY
LEVER,STARTER,BLACK (Ref # 29)	46096-008-10	
WASHER SPRING 6MM (Ref # 30)	461F0600	
BOLT,6X10 (Ref # 31)	112G0610	
RUBBER,L.H GRIP (Ref # 32)	46075-029	
REAR VIEW MIRROR,R.H (Ref # 33)	56002-020	
REAR VIEW MIRROR,L.H (Ref # 34)	56003-009	
REAR VIEW MIRROR,L.H (Ref # 34)	56003-009	
CAP-RR VIEW MIRROR (Ref # 35)	92102-009	