

1978 KZ200-A1 PARTS LIST

FOOTRESTS/STANDS/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
STEP-ASSY (Ref # 1)	34027-1103	2
WASHER,PLAIN (Ref # 2)	92022-250	1
PIN COTTER 2.5X16 (Ref # 3)	550D2516	1
PIN-FOOTREST BAR FIT (Ref # 4)	92043-080	1
DAMPER,RUBBER (Ref # 5)	92075-306	1
DAMPER,RUBBER (Ref # 6)	92075-1029	2
BAR,FOOTREST (Ref # 7)	34004-008	1
HOLDER,FOOTREST (Ref # 9)	13091-1003	1
WASHER SPRING 8MM (Ref # 10)	461F0800	2
BOLT-SMALL-UPSET,8X16 (Ref # 11)	115G0816	1
PEDAL,BRAKE (Ref # 12)	43001-077	1
NUT 6MM (Ref # 13)	311B0600	1
BOLT-UPSET (Ref # 14)	112G0625	1
PIN,BRAKE ROD FITTING (Ref # 15)	92043-090	1
SPRING,BRAKE PEDAL (Ref # 16)	43005-029	1
WASHER,8.5X20X1.6 (Ref # 17)	92022-1561	1
NUT,CAP AND LOCK,8MM (Ref # 19)	92019-013	1
ROD,BRAKE (Ref # 20)	43011-028	1
PIN COTTER 2.0X15 (Ref # 21)	550D2015	1
SPRING,BRAKE ROD (Ref # 22)	43012-001	1
PIN BRAKE (Ref # 23)	92043-039	1
NUT-BRAKE ROD ADJUST (Ref # 24)	92015-042	1
PIN COTTER 3.0X30 (Ref # 25)	550D3030	1
SPRING,MAIN STAND (Ref # 26)	34023-016	1
STAND-MAIN (Ref # 27)	34011-050	1
SHAFT MAIN STAND (Ref # 28)	34019-011	1
SPRING,SIDE STAND (Ref # 29)	34025-011	1
BOLT,SIDE STAND FITNG (Ref # 30)	92003-226	1
WASHER,LOCK (Ref # 31)	92024-078	1

1978 KZ200-A1 PARTS LIST

FOOTRESTS/STANDS/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
STOPPER,SIDE STAND (Ref # 32)	32085-1009	1
STAND-SIDE (Ref # 33)	34024-070	1
SPRING,SIDE STAND (Ref # 34)	34025-010	1
NUT,LOCK,10MM (Ref # 35)	92019-021	1