



1975 F11-B

PARTS DIAGRAM

OIL PUMP



1975 F11-B

PARTS LIST

OIL PUMP

| ITEM NAME | PART NUMBER | QUANTITY |
|---------------------------------|-------------|----------|
| OIL PUMP ASSY (Ref # 1) | 16082-043 | |
| GASKET,OIL PUMP (Ref # 2) | 11060-1160 | |
| SCREW PAN CROSS,5X28 (Ref # 3) | 220B0528 | |
| SCREW-PAN-CROS (Ref # 4) | 220B0514 | |
| WASHER OIL PUMP (Ref # 5) | 92022-037 | |
| PIPE-OIL (Ref # 6) | 16134-019 | |
| BOLT-BANJO,6MM (Ref # 7) | 92060-013 | |
| WASHER OIL PUMP BANJ (Ref # 8) | 92022-077 | |
| PIPE-OIL (Ref # 9) | 16134-020 | |
| BOLT-BANJO (Ref # 10) | 92060-017 | |
| GASKET CHECK VALVE (Ref # 11) | 92065-058 | |
| GASKET CHECK VALVE (Ref # 12) | 92065-023 | |
| CONNECTOR BANJO (Ref # 13) | 92061-009 | |
| SPRING-OIL PUMP LEVE (Ref # 14) | 16093-005 | |
| SEAL-OIL,CAMSHAFT,"X (Ref # 15) | 92049-1294 | |
| "0" RING,LOWER CAP (Ref # 16) | 16090-003 | |
| "0" RING,UPPER CAP (Ref # 17) | 16088-002 | |
| "0" RING,OIL PUMP SH (Ref # 18) | 16090-002 | |
| OIL SEAL OIL PUMP SH (Ref # 19) | 16091-001 | |
| LEVER-OIL PUMP CABLE (Ref # 20) | 16096-010 | |