


# 1978 KZ400-A2

## PARTS DIAGRAM

### REAR HUB/BRAKE/CHAIN



# 1978 KZ400-A2

## PARTS LIST

### REAR HUB/BRAKE/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
DRUM ASY,RR BK,BUFF (Ref # 1)	42005-044-80	
BEARING BALL #6303 (Ref # 2)	601B6303	
SPACER,RR HUB BEARING (Ref # 3)	42010-027	
DAMPER REAR HUB SHOCK (Ref # 4)	42014-008	
BEARING BALL #6303Z (Ref # 5)	601B6303Z	
"0" RING,60MM (Ref # 6)	671B2560	
PANEL-ASY,RR BRK,BUFF (Ref # 7)	42006-055-80	
PIN COTTER 2.0X25 (Ref # 8)	550D2025	
WASHER,BRAKE SHOE (Ref # 9)	41045-007	
SHOE REAR BRAKE (Ref # 10)	42019-003	
SPRING BRAKE SHOE (Ref # 11)	41049-003	
CAM SHAFT,REAR BRAKE (Ref # 12)	42026-024	
DUST SHIELD BRAKE CAM (Ref # 13)	41051-001	
INDICATOR,RR BK SHOE (Ref # 14)	41085-016	
LEVER,REAR BRAKE CAM (Ref # 15)	42029-036	
BOLT-SMALL-UPSET 8X25 (Ref # 16)	115G0825	
COLLAR,REAR AXLE (Ref # 17)	42032-053	
WASHER SLEEVE (Ref # 18)	42046-009	
NUT CASTLE,16MM (Ref # 19)	92015-055	
PIN-COTTER,4.0X35 (Ref # 20)	550D4035	
REAR SPROCKET,45T (Ref # 21)	42041-145	
COUPLING ASSY,RR HUB (Ref # 22)	42008-024	
NUT,10MM (Ref # 23)	314B1000	
WASHER SPROCKET LOCK (Ref # 24)	92088-005	
NUT SLEEVE (Ref # 25)	42045-006	
WASHER,PLAIN,24MM (Ref # 26)	92022-293	
COLLAR,RR HUB COUPLNG (Ref # 27)	42037-026	
OIL SEAL WTC35527 (Ref # 28)	92052-006	
BEARING BALL #6205 (Ref # 29)	601B6205	

# 1978 KZ400-A2

## PARTS LIST

### REAR HUB/BRAKE/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
SLEEVE,RR HUB COUPLNG (Ref # 30)	42036-021	
BOLT, RR SPROCKET FIT (Ref # 31)	92003-156	
AXLE,REAR (Ref # 32)	42031-050	
CHAIN,525X94 SH (Ref # 33)	92057-029	
CHAIN JOINT 530 (Ref # 34)	92058-008	