


1979 KZ400-B2 PARTS DIAGRAM

FRONT HUB



1979 KZ400-B2 PARTS LIST

FRONT HUB

ITEM NAME	PART NUMBER	QUANTITY
PIN-COTTER,4.0X35 (Ref # 1)	550D4035	
NUT CASTLE 16M/M (Ref # 2)	42045-014	
WASHER PLAIN 16MM (Ref # 3)	410B1600	
GEAR BOX ASSY (Ref # 4)	41078-1004	
GEAR,SPEEDOMETER (Ref # 5)	41060-1010	
OIL SEAL,BJN30427-C3 (Ref # 6)	92049-1057	
RECEIVER,GEAR (Ref # 7)	41064-013	
PIN,SPRING (Ref # 8)	41082-001	
WASHER THRST SPD PINI (Ref # 9)	41063-001	
PINION,SPEEDOMETER (Ref # 10)	41060-017	
BUSH,SPEEDMETER CABLE (Ref # 11)	41062-005	
DRUM-ASSY,FR BRK (Ref # 12)	41034-1003	
BEARING BALL #6203 (Ref # 13)	601B6203	
COLLAR,BRG (Ref # 14)	41039-028	
RING, SNAP,43.5M/M (Ref # 15)	92033-1040	
OIL SEAL (Ref # 16)	654A254008	
DUST COVER (Ref # 17)	41042-016	
WASHER PLAIN 5MM (Ref # 18)	411B0500	
SCREW PAN HEAD 5X12 (Ref # 19)	220B0512A	
BOLT (Ref # 20)	92001-158	
WASHER,LOCK (Ref # 21)	92088-023	
COVER,DUST (Ref # 22)	49016-1001	
COLLAR,FRONT AXLE (Ref # 23)	92027-1008	
AXLE,FRONT (Ref # 24)	41068-1002	
COVER,DUST,HUB (Ref # 25)	49016-1021	
COVER,DUST,HUB (Ref # 26)	49016-1022	