


1981 KX420

PARTS DIAGRAM

SWING ARM (KX420-A1)

Kawasaki
Let the Good Times Roll®



1981 KX420

PARTS LIST

SWING ARM (KX420-A1)

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-SWING ARM (Ref # 1)	33032-1020	1
SLEEVE,SWING ARM (Ref # 2)	42036-1031	1
NUT-LOCK,14MM (Ref # 3)	92019-011	1
ARM,SWING (Ref # 4)	33001-1043	1
CAP,SWING ARM (Ref # 5)	11012-1099	1
SHIM,SWING ARM (Ref # 6)	92025-1116	1
BUSHING (Ref # 7)	92028-1072	1
GUIDE,CHAIN,FRONT (Ref # 8)	12053-1046	1
GUARD,CHAIN (Ref # 9)	55020-1038	1
BOLT-UPSET (Ref # 10)	112G0660	1
WASHER 6.5X20X1.6T (Ref # 11)	92022-125	1
GUIDE,CHAIN,REAR (Ref # 12)	12053-1039	1
NUT (Ref # 13)	92019-008	1
BOLT-UPSET,6X20 (Ref # 14)	112G0620	1
ADJUSTER,CHAIN (Ref # 15)	33040-1012	1
NUT,8MM (Ref # 16)	312G0800	1
BOLT,CHAIN ADJUSTER (Ref # 17)	92001-1027	1