


1978 SR PARTS DIAGRAM

AIR CLEANER



1978 SR PARTS LIST

AIR CLEANER

| ITEM NAME | PART NUMBER | QUANTITY |
|--------------------------------------|-------------|----------|
| BAFFLE PLT,AIR CLEANER (Ref # 1) | 11019-003 | 1 |
| WASHER PLAIN 6MM (Ref # 2) | 411B0600 | 1 |
| BOLT-UPSET (Ref # 3) | 112G0618 | 1 |
| FILTER-ASSY (Ref # 4) | 11010-1079 | 2 |
| CAP,AIR CLEANER (Ref # 5) | 11012-069 | 1 |
| ELEMENT,AIR CLNR (Ref # 6) | 11013-1006 | 1 |
| HOLDER,INLET PIPE (Ref # 7) | 11033-006 | 1 |
| GASKET,HOLDER (Ref # 8) | 11039-003 | 1 |
| INLET DUCT,#2,3 (Ref # 9) | 11015-057 | 1 |
| INLET PIPE,#1.4 (Ref # 10) | 11015-063 | 1 |
| SPRING COIL (Ref # 11) | 92081-047 | 1 |
| BRACKET,AIR CLEANER (Ref # 12) | 32070-038 | 1 |
| UNAVAILABLE IN PRICE BOOK (Ref # 13) | 700Q6200 | 1 |
| TUBE,BREATHING (Ref # 14) | 92059-137 | 1 |
| CLAMP BREATHING PIPE (Ref # 15) | 92037-028 | 1 |
| WASHER SPRING 6MM (Ref # 16) | 461F0600 | 1 |
| BOLT-UPSET,6X12 (Ref # 17) | 112G0612 | 1 |