


# 1980 LTD II

## PARTS DIAGRAM

### AIR CLEANER



# 1980 LTD II

## PARTS LIST AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
BOLT-UPSET,6X16 (Ref # 1)	112G0616	2
AIR CLEANER ASSY (Ref # 2)	11010-109	1
BOLT-UPSET,6X20 (Ref # 3)	112G0620	3
ELEMENT,AIR CLNR (Ref # 4)	11013-051	1
PIPE,INLET (Ref # 5)	11015-049	1
CONNECTOR (Ref # 6)	11026-018	2
HOLDER (Ref # 7)	11033-004	1
GASKET (Ref # 8)	11039-001	1
PLATE,INLET PIPE (Ref # 9)	11040-004	2
PLATE,INLET PIPE (Ref # 10)	11040-005	2
PLATE,AIR CLNR BODY (Ref # 11)	11040-006	1
SCREW PAN HEAD 4X16 (Ref # 12)	220B0416	6
WASHER SPRING 4MM (Ref # 13)	461F0400	6
WASHER PLAIN 4MM (Ref # 14)	410B0400	6
NUT 6MM (Ref # 15)	311B0600	6
CLAMP,BREATHER HOSE (Ref # 16)	92037-192	2
TUBE (Ref # 17)	92059-121	1
WASHER 6.5X20X1.6T (Ref # 18)	92022-125	2
CLAMP (Ref # 19)	92037-171	2