


1976 LTD

PARTS DIAGRAM

ENGINE COVERS



1976 LTD

PARTS LIST ENGINE COVERS

| ITEM NAME | PART NUMBER | QUANTITY |
|---------------------------------|--------------|----------|
| COVER,L.H ENGINE (Ref # 1) | 14031-1020 | 1 |
| COVER,L.H ENGINE (Ref # 1) | 14031-1020 | 1 |
| GASKET,GENERATOR COV (Ref # 2) | 11060-1075 | 1 |
| COVER,FRONT CHAIN (Ref # 3) | 14026-026 | 1 |
| OIL SEAL SB12205 (Ref # 4) | 92049-004 | 3 |
| COVER,TRANSMISSION (Ref # 5) | 14025-1106 | 1 |
| OIL SEAL,TC7187 (Ref # 6) | 92050-048 | 1 |
| OIL SEAL SC325210 (Ref # 7) | 92050-024 | 1 |
| GASKET,MISSION COVER (Ref # 8) | 14058-004 | 1 |
| COVER,OIL PUMP (Ref # 9) | 14026-012 | 1 |
| GASKET,CHAIN COVER (Ref # 10) | 14045-015 | 1 |
| COVER,ENGINE SPROCKE (Ref # 11) | 14024-008 | 1 |
| COVER,R.H ENGINE (Ref # 12) | 14032-083 | 1 |
| GASKET,RH ENGINE COV (Ref # 13) | 11060-1071 | 1 |
| COVER,BREAKER POINT (Ref # 14) | 14027-023-80 | 1 |
| COVER,CLUTCH (Ref # 15) | 14032-121 | 1 |
| GASKET,CLUTCH (Ref # 16) | 14046-024 | 1 |
| GAUGE,OIL LEVEL (Ref # 17) | 52015-004 | 1 |
| COVER,KICK SHAFT,BAR (Ref # 18) | 14032-075-2H | 1 |
| GASKET,KICK COVER (Ref # 19) | 14046-025 | 1 |
| OIL SEAL,SC22325 (Ref # 20) | 92049-1048 | 1 |
| SCREW PAN HEAD 6X12 (Ref # 21) | 220B0612 | 2 |
| SCREW PAN HEAD 6X22 (Ref # 22) | 220B0622 | 11 |
| SCREW PAN HEAD 6X25 (Ref # 23) | 220B0625 | 11 |
| SCREW PAN HEAD 6X28 (Ref # 24) | 220B0628 | 1 |
| SCREW PAN HEAD 6X30 (Ref # 25) | 220B0630 | 7 |
| SCREW PAN HEAD 6X40 (Ref # 26) | 220B0640 | 8 |
| BOLT,6X70 (Ref # 27) | 110G0670 | 2 |
| BOLT-UPSET,6X125 (Ref # 28) | 112G06125 | 2 |

1976 LTD

PARTS LIST ENGINE COVERS

| ITEM NAME | PART NUMBER | QUANTITY |
|--------------------------------|-------------|----------|
| OIL SEAL,S25407R (Ref # 29) | 92050-047 | 1 |
| GASKET,POINT CAP (Ref # 30) | 14050-006 | 1 |
| SCREW PAN HEAD 6X12 (Ref # 31) | 220B0612 | 2 |