


# 1974 KX450

## PARTS DIAGRAM

### KICKSTARTER MECHANISM ('74 KX 450)



# 1974 KX450

## PARTS LIST

### KICKSTARTER MECHANISM ('74 KX 450)

ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 1)	92022-252	1
CIRCLIP (Ref # 2)	92033-026	2
SPRING (Ref # 3)	92081-097	1
WASHER-PLAIN 25MM (Ref # 4)	92022-159	1
RATCHET (Ref # 5)	13078-007	1
GEAR,KICKSTARTER (Ref # 6)	13068-029	1
SHAFT,KICKSTARTER (Ref # 7)	13066-031	1
GUIDE,KICKSTARTER (Ref # 8)	13070-007	1
SPRING-KICKSTARTER (Ref # 9)	92082-003	1
PEDAL ASSY (Ref # 10)	13058-046	1
RUBBER KICK PEDAL (Ref # 11)	13063-004	1
PIN-KICK PEDAL (Ref # 12)	92043-081	1
BOLT-KICK PEDAL (Ref # 13)	92001-110	1
BOSS-KICK PEDAL (Ref # 14)	13061-010	1
WASHER PLAIN 8MM (Ref # 15)	410B0800	1
CIRCLIP 5MM (Ref # 16)	482K5000	1
SPRING KICK PEDAL (Ref # 17)	92081-020	1
BALL STEEL 1/4' (Ref # 18)	600A0800	1
STOPPER,KICKSTARTER (Ref # 19)	13072-014	1
GUIDE,KICKSTARTER (Ref # 20)	13206-1003	1
WASHER,LOCK (Ref # 21)	92031-008	1
BOLT-UPSET,6X16 (Ref # 22)	112G0616	2
BOLT-UPSET,6X16 (Ref # 22)	112G0616	AL