



## 1981 KE175 PARTS LIST

GEAR CHANGE DRUM & FORKS ('80-'81 KE175-

| ITEM NAME                        | PART NUMBER | QUANTITY |
|----------------------------------|-------------|----------|
| FORK,SHIFT,LOW,2ND,3R (Ref # 1)  | 13140-1013  | 1        |
| FORK,SHIFT 4TH&TOP (Ref # 2)     | 13140-1014  | 1        |
| ROD-SHIFT,10X102 (Ref # 3)       | 49047-1060  | 1        |
| DRUM ASSY,GEAR CHANGE (Ref # 4)  | 13239-1029  | 1        |
| DRUM ASSY,GEAR CHANGE (Ref # 4)  | 13239-1039  | 1        |
| HOLDER,CHANGE DRM PIN (Ref # 5)  | 13091-1070  | 1        |
| HOLDER,DRUM PIN (Ref # 5)        | 13091-1082  | 1        |
| SCREW PAN HEAD 6X30 (Ref # 6)    | 220B0630    | 1        |
| BOLT,SOCKET,6X30,BLAC (Ref # 6)  | 120S0630    | 1        |
| PIN,GEAR CHANGE DRUM (Ref # 7)   | 92042-042   | 1        |
| PLATE CHANGE DRUM PIN (Ref # 8)  | 13142-008   | 1        |
| PIN-DOWEL,4X6 (Ref # 9)          | 610A0406    | 1        |
| BEARING,BALL,#6905 (Ref # 10)    | 92045-036   | 1        |
| BEARING BALL #6004 (Ref # 10)    | 601B6004    | 1        |
| ROTOR,NEUTRAL INDICTR (Ref # 11) | 21007-1003  | 1        |
| WASHER PLAIN 6MM (Ref # 12)      | 410B0600    | 1        |
| SCREW PAN HEAD 6X16 (Ref # 13)   | 220B0616    | 2        |
| GASKET NEUTRAL SWITCH (Ref # 14) | 13146-002   | 1        |
| SWITCH,NEUTRAL (Ref # 15)        | 13151-1001  | 1        |