




1968 Sidewinder PARTS DIAGRAM

REAR HUB/BRAKE/CHAIN



1968 Sidewinder PARTS LIST

REAR HUB/BRAKE/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
PANEL ASSY REAR BRAKE (Ref # 1)	42006-008	
.SHOE,BRAKE (Ref # 2)	42019-011	
SHOE,BRAKE (Ref # 2)	42019-011	
.SPRING-BRAKE SHOE (Ref # 3)	42020-004	
.CAM SHAFT,REAR BRAKE (Ref # 4)	42026-021	
CAM SHAFT,REAR BRAKE (Ref # 4)	42026-021	
.BOLT 6X35 (Ref # 5)	110R0635	
.WASHER PLAIN 6MM (Ref # 6)	410B0600	
.NUT 6MM (Ref # 7)	311B0600	
.DUST SHIELD BRAKE CAM (Ref # 8)	41051-001	
.UNAVAILABLE IN PRICE BOOK (Ref # 9)	42029-007	
DRUM ASSY REAR BRAKE (Ref # 10)	42005-010	
.BEARING, BALL, #6202 (Ref # 11)	601B6202Z	
.SPACER RR HUB BEARING (Ref # 12)	42010-004	
.BEARING BALL #6202 (Ref # 13)	601B6202	
.DAMPER REAR HUB SHOCK (Ref # 14)	42014-009	
COUPLING ASSY RR HUB (Ref # 15)	42008-003	
.BUSH OIL SEAL (Ref # 16)	42037-007	
.NUT,20MM (Ref # 17)	42045-015	
.WASHER PLAIN 22MM (Ref # 18)	42046-003	
.UNAVAILABLE IN PRICE BOOK (Ref # 19)	42036-007	
.OIL SEAL WTC30528 (Ref # 20)	92052-007	
.BEARING BALL #6304 (Ref # 21)	601B6304	
.BOLT-REAR SPROCKET (Ref # 22)	92003-087	
.WASHER SPROCKET LOCK (Ref # 23)	92088-005	
.NUT 10MM (Ref # 24)	315B1000	
AXLE REAR (Ref # 25)	42031-015	
COLLER REAR HUB R.H (Ref # 26)	42032-011	
NUT,14MM (Ref # 27)	314B1400	

1968 Sidewinder PARTS LIST

REAR HUB/BRAKE/CHAIN

ITEM NAME	PART NUMBER	QUANTITY
UNAVAILABLE IN PRICE BOOK (Ref # 28)	42046-006	
WASHER PLAIN 14MM (Ref # 28)	411B1400	
NUT CASTLE 14MM (Ref # 29)	321B1400	
PIN COTTER 2.0X15 (Ref # 30)	550D2015	
REAR SPROCKET 39T (Ref # 31)	42041-029	
REAR SPROCKET 37T (Ref # 31)	42041-028	
REAR SPROCKET 41T (Ref # 31)	42041-064	
UNAVAILABLE IN PRICE BOOK (Ref # 32)	695Z5296	
.CHAIN JOINT 530 (Ref # 33)	92058-008	