


# 1982 CSR Belt

## PARTS DIAGRAM

### REAR HUB/BRAKE/BELT

F2240-0056



# 1982 CSR Belt

## PARTS LIST

### REAR HUB/BRAKE/BELT

ITEM NAME	PART NUMBER	QUANTITY
SPROCKET-ASSY,RR,50T (Ref # 21053)	21053-1010	1
DRUM-ASSY,RR BRK (Ref # 41034)	41034-1005	1
PANEL-ASY,RR BRK (Ref # 41035)	41035-1089	1
SHOE-BRAKE (Ref # 41048)	41048-1069	2
CAM,BRAKE (Ref # 41050)	41050-1001	1
LEVER,BRAKE CAM (Ref # 41053)	41053-1001	1
AXLE,RR (Ref # 41068)	41068-1067	1
INDICATOR,BRAKE SHOE (Ref # 41085)	41085-004	1
COUPLING-ASSY,RR (Ref # 42033)	42033-1044	1
SLEEVE,COUPLING (Ref # 42036)	42036-1002	1
RING,REAR HUB SPROCKE (Ref # 43058)	43058-1016	1
RING,REAR HUB SPROCKE (Ref # 43058A)	43058-1016	1
BELT,DRIVE (Ref # 59011)	59011-1002	1
BOLT, RR SPROCKET FIT (Ref # 92001)	92003-156	4
SCREW,5X10 (Ref # 92009)	92009-1131	8
NUT CASTLE,16MM (Ref # 92015)	92015-055	1
WASHER SPROCKET LOCK (Ref # 92022)	92088-005	2
COLLAR,REAR HUB BRG. (Ref # 92027)	92027-1013	1
COLLAR,RR AXLE,RH (Ref # 92027A)	92027-1256	1
COLLAR (Ref # 92027B)	92027-1368	1
CIRCLIP,47M/M (Ref # 92033)	92033-1042	1
RING,SNAP,56.2M/M (Ref # 92033A)	92033-1043	1
BEARING-BALL (Ref # 92045)	601B6303U	1
OIL SEAL WTC35527 (Ref # 92049)	92052-006	1
DAMPER,REAR HUB SHOCK (Ref # 92075)	92075-1008	1
SPRING-BRAKE SHOE (Ref # 92081)	42020-004	2
DUST SHIELD-BRAKE CAM (Ref # 92093)	41051-003	1
BOLT HEX HEAD 8X28 (Ref # 114)	114G0828	1
NUT,10MM (Ref # 314)	314B1000	4

# 1982 CSR Belt

## PARTS LIST

### REAR HUB/BRAKE/BELT

ITEM NAME	PART NUMBER	QUANTITY
WASHER PLAIN 8MM (Ref # 410)	410B0800	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING BALL #6205 (Ref # 601)	601B6205	1
BEARING BALL #6303 (Ref # 601A)	601B6303	1
"0" RING,60MM (Ref # 671)	671B2560	1