


2011 Ultra 300X PARTS DIAGRAM

Fuel Injection



2011 Ultra 300X PARTS LIST

Fuel Injection

ITEM NAME	PART NUMBER	QUANTITY
BOLT,6X8 (Ref # 110)	110R0608	1
BOLT-WP,6X20 (Ref # 156)	156R0620	1
SCREW-PAN-CROSS,4X20 (Ref # 220)	220R0420	1
BRACKET,ECU&RELAY (Ref # 11054)	11054-3743	1
BRACKET,FUSE (Ref # 11055)	11055-3713	1
BRACKET,SWITCH (Ref # 11056)	11056-1114	1
BRACKET,REGULATOR&VDS (Ref # 11056A)	11056-3702	1
HOLDER,HARNESS (Ref # 13280)	13280-3760	1
REGULATOR-VOLTAGE (Ref # 21066)	21066-3718	1
CONTROL UNIT-ELECTRONIC (Ref # 21175)	21175-3744	1
SENSOR,TEMP (Ref # 21176)	21176-3774	1
FUSE,MINI BLADE,20A,YELLOW (Ref # 26006)	26006-3704	1
HARNESS (Ref # 26031)	26031-1223	1
RELAY-ASSY (Ref # 27002)	27002-3703	1
RELAY-ASSY (Ref # 27002A)	27002-3704	1
SWITCH (Ref # 27010)	27010-0710	1
SWITCH,VDS (Ref # 27010A)	27010-3785	1
BOLT,6X16 (Ref # 92002)	92002-3728	1
BOLT,6X12 (Ref # 92002A)	92002-3763	1
WASHER,6.5X20X1.5 (Ref # 92022)	92022-3710	1
CLAMP,L=100 (Ref # 92037)	92037-3736	1
RIVET (Ref # 92039)	92039-3714	1
RIVET (Ref # 92039A)	92039-3788	1
BAND,L=188.85 (Ref # 92072)	92072-0105	1
BAND,L=372.24 (Ref # 92072A)	92072-3883	1
BOLT,6X18 (Ref # 92150)	92150-3729	1