


2013 JET SKI® ULTRA® 300X

PARTS DIAGRAM

Control

F3177



2013 JET SKI® ULTRA® 300X

PARTS LIST

Control

ITEM NAME	PART NUMBER	QUANTITY
O RING,11MM (Ref # 670)	670B2011	1
BRACKET (Ref # 11056)	11056-0711	1
FLOAT (Ref # 16031)	16031-3993	1
ACTUATOR,JET PUMP (Ref # 16172)	16172-0027	1
COVER-SEAL,TILT CABLE (Ref # 49016)	49016-3702	1
NUT,20MM (Ref # 92015)	92015-526	1
WASHER (Ref # 92022)	92022-535	1
RING-SNAP,7.7X17.5X3.0 (Ref # 92033)	92033-3737	1
RIVET (Ref # 92039)	92039-3714	2
GROMMET (Ref # 92071)	92071-3840	2
BAND,BATTERY (Ref # 92072)	92072-3841	2
BAND,L=100.08 (Ref # 92072A)	92072-3882	3
CLAMP,L=150 (Ref # 92171)	92171-3717	1