


# 1988 Mojave 110E

## PARTS DIAGRAM

### Transmission

E1361-0181



# 1988 Mojave 110E

## PARTS LIST

### Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT,13T (Ref # 13127)	13127-1119	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1045	1
GEAR,INPUT 2ND,18T (Ref # 13129)	13129-1244	1
GEAR,OUTPUT LOW,43T (Ref # 13129A)	13129-1248	1
GEAR,OUTPUT 3RD,34T (Ref # 13129B)	13129-1618	1
GEAR,INPUT 3RD&4TH,22&22T (Ref # 13129C)	13129-1820	1
GEAR,INPUT 5TH,29T (Ref # 13129D)	13129-1821	1
GEAR,OUTPUT 4TH,27T (Ref # 13129E)	13129-1822	1
GEAR,OUTPUT 5TH,28T (Ref # 13129F)	13129-1823	1
GEAR,OUTPUT 2ND,38T (Ref # 13129G)	13129-1857	1
SHIFTER (Ref # 13139)	13139-1051	1
SPROCKET-OUTPUT,12T (Ref # 13144)	13144-1072	1
SPACER,17.2X23X0.5 (Ref # 92026)	92026-1037	2
COLLAR,17X22X14.3 (Ref # 92027)	92027-1511	1
RING-SNAP,17MM (Ref # 92033)	92033-1060	6
RING-O,17MM (Ref # 92055)	92055-1097	1
CIRCLIP-TYPE-C,17MM (Ref # 480)	480J1700	1