


## 1987 Mojave 110E PARTS DIAGRAM

Recoil Starter

E3040-0004



## 1987 Mojave 110E PARTS LIST

Recoil Starter

ITEM NAME	PART NUMBER	QUANTITY
GASKET,RECOIL STARTER (Ref # 11009)	11009-1598	1
CAP,RECOIL GRIP (Ref # 11012)	11012-1420	1
GUIDE,RECOIL (Ref # 13070)	13070-1123	1
PLATE-FRICTION,RECOIL (Ref # 13088)	13088-1067	1
SHAFT,RECOIL (Ref # 13107)	13107-1129	1
PAWL,RECOIL (Ref # 13165)	13165-1110	1
COVER,RECOIL (Ref # 14024)	14025-1966	1
GRIP,RECOIL (Ref # 46075)	46075-1073	1
PULLEY-STARTING (Ref # 49080)	49080-1053	1
STARTER-RECOIL (Ref # 49088)	49088-1053	1
REEL (Ref # 59101)	59101-1108	1
ROPE,RECOIL (Ref # 59106)	59106-1102	1
NUT,6MM (Ref # 92015)	92015-1464	1
PIN,RECOIL (Ref # 92043)	92043-1259	1
SPRING,RECOIL (Ref # 92081)	92081-1772	1
SPRING (Ref # 92081A)	92081-1773	1
SCREW-PAN-CROS (Ref # 220)	220X0650	1
SCREW-PAN-CROS (Ref # 220A)	220X0660	1