

2008 Ninja[®] ZX[™]-6R

PARTS DIAGRAM

Generator



E1810

Ref. Crankshaft/Piston (s)

Ref. Crankcase

21007

92200

92153

92151

21003

92151

92015

92015

92152

92152

Ref. Rear Fender (s)

Ref. Rear Fender (s)

Ref. Rear Fender (s)


11054

92037

21066

Ref. Throttle

130



2008 Ninja® ZX™-6R

PARTS LIST

Generator

ITEM NAME

PART NUMBER

QUANTITY
