


# 2005 KLX125L

## PARTS DIAGRAM

### Front Hub

F2230



# 2005 KLX125L

## PARTS LIST

### Front Hub

ITEM NAME	PART NUMBER	QUANTITY
PIN-HAIR,COTTER (Ref # 39092)	39092-S005	1
TIRE,FR (Ref # 41009)	41009-S007	1
TUBE-TIRE (Ref # 41022)	41022-S003	1
BAND-RIM (Ref # 41023)	41023-S003	1
RIM (Ref # 41025A)	41025-S018	1
SPOKE-ASSY (Ref # 41026A)	41026-S012	1
DRUM-ASSY,FRONT WHEEL (Ref # 41034)	41034-S002	1
AXLE,FR (Ref # 41068)	41068-S005	1
DISC (Ref # 41080)	41080-S004	1
SPACER,FRONT HUB BEARING (Ref # 92026)	92026-S050	1
SPACER,FRONT AXLE (Ref # 92026A)	92026-S051	2
BEARING-BALL,FRONT HUB (Ref # 92045)	92045-S002	2
SCREW (Ref # 92172)	92172-S109	3
WASHER (Ref # 92200)	92200-S079	1
NUT (Ref # 92210)	92210-S064	1
NUT (Ref # 92210A)	92210-S066	3