


2008 Ninja® ZX™-6R PARTS DIAGRAM

Front Brake



2008 Ninja® ZX™-6R PARTS LIST

Front Brake

ITEM NAME	PART NUMBER	QUANTITY
GASKET,DISC PLATE (Ref # 11061)	11061-0029	2
DISC,FR,HOUSING BLK+DISC SIL (Ref # 41080)	41080-0077-5C	2
PISTON-CALIPER (Ref # 43048)	43048-0005	8
PACKING (Ref # 43049)	43049-0006	8
PACKING (Ref # 43049A)	43049-0007	8
BREATHER (Ref # 43056)	43056-1055	2
CAP-BREATHER (Ref # 43057)	43057-1001	2
CALIPER-SUB-ASSY,FR,RH,BLACK (Ref # 43080)	43080-0046-DJ	1
CALIPER-SUB-ASSY,FR,LH,BLACK (Ref # 43080A)	43080-0047-DJ	1
PAD-ASSY-BRAKE (Ref # 43082)	43082-0072	2
PIN,PAD (Ref # 92043)	92043-0105	4
SEAL-OIL (Ref # 92049)	92049-1448	2
SPRING,PAD (Ref # 92145)	92145-0436	4
BOLT,SOCKET,8X30 (Ref # 92150)	92150-1771	10
BOLT,TORX,8X38 (Ref # 92153)	92153-1093	6
BOLT,SOCKET,10X60 (Ref # 92153A)	92153-1837	4