


2003 KLX400SR

PARTS DIAGRAM

Transmission

E1361



2003 KLX400SR

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT (Ref # 13127)	13127-S008	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-S010	1
SPROCKET-OUTPUT,15T (Ref # 13144)	13144-S008	1
GEAR,INPUT 2ND,15T (Ref # 13262)	13262-S024	1
GEAR,INPUT 3RD,16T (Ref # 13262A)	13262-S025	1
GEAR,INPUT 4TH,22T (Ref # 13262B)	13262-S026	1
GEAR,INPUT 5TH,22T (Ref # 13262C)	13262-S027	1
GEAR,OUTPUT LOW,32T (Ref # 13262D)	13262-S028	1
GEAR,OUTPUT 2ND,26T (Ref # 13262E)	13262-S029	1
GEAR,OUTPUT 3RD,22T (Ref # 13262F)	13262-S030	1
GEAR,OUTPUT 4TH,24T (Ref # 13262G)	13262-S031	1
GEAR,OUTPUT 5TH,19T (Ref # 13262H)	13262-S032	1
RETAINER (Ref # 14020)	14020-S008	2
RETAINER,KICK (Ref # 14020A)	14020-S011	1
RETAINER,DRIVE SHAFT (Ref # 14020B)	14020-S012	1
SPACER,17X30.5X16.3 (Ref # 92026)	92026-S124	1
SPACER (Ref # 92026A)	92026-S125	1
RING-SNAP (Ref # 92033)	92033-S049	3
RING-SNAP (Ref # 92033A)	92033-S050	1
BEARING-BALL,25X52X15 (Ref # 92045)	92045-S018	1
BEARING-BALL,17X40X12 (Ref # 92045A)	92045-S035	1
BEARING-BALL (Ref # 92045B)	92045-S051	1
BEARING-BALL (Ref # 92045C)	92045-S057	1
SEAL-OIL,30X40X6 (Ref # 92049)	92049-S019	1
RING-O,D=2.5 (Ref # 92055)	92055-S034	1
CHAIN,DRIVE(RK520KZ0X112L) (Ref # 92057)	92057-S013	1
JOINT-CHAIN (Ref # 92058)	92058-S004	1
BUSHING (Ref # 92139)	92139-S032	1
BUSHING (Ref # 92139A)	92139-S033	1

2003 KLX400SR

PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
SCREW (Ref # 92172)	92172-S012	2
SCREW (Ref # 92172A)	92172-S170	2
SCREW,RETAINER (Ref # 92172B)	92172-S171	2
SHIM,17X30X1.0 (Ref # 92180)	92180-S014	1
SHIM,20X30X1.0 (Ref # 92180A)	92180-S015	1
WASHER (Ref # 92200)	92200-S145	1
WASHER,20X34X1.0 (Ref # 92200A)	92200-S187	1
WASHER (Ref # 92200B)	92200-S188	1
NUT (Ref # 92210)	92210-S126	1