


2018 VULCAN® S ABS SE

PARTS DIAGRAM

Air Cleaner



2018 VULCAN® S ABS SE

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-0856	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-0745	1
DUCT,INTAKE,LH (Ref # 14073)	14073-0799	1
DUCT,INTAKE,RH (Ref # 14073A)	14073-0800	1
VALVE,AIR SWITING (Ref # 16126)	16126-0019	1
PLUG,DRAIN (Ref # 92066)	92066-0782	1
SEAL (Ref # 92093)	92093-0610	1
SEAL,ELEMENT (Ref # 92093A)	92093-0611	1
DAMPER (Ref # 92161)	92161-0309	1
DAMPER (Ref # 92161A)	92161-1374	1
DAMPER (Ref # 92161B)	92161-1428	2
CLAMP (Ref # 92170)	92170-1017	1
SCREW,5X25 (Ref # 92172)	92172-0891	9
CLAMP,10MM (Ref # 92173)	92173-1044	2
CLAMP (Ref # 92173A)	92173-1698	1
TUBE,BREATHER (Ref # 92192)	92192-0958	1
TUBE,ASV-HEAD (Ref # 92192A)	92192-0960	1
TUBE,DRAIN,L=245 (Ref # 92192B)	92192-1380	1
TUBE,ASV-A/C (Ref # 92192C)	92192-1381	1